



QUALITY HARDWARE

PADBOLT

Installation Tips

1. If door frame/post are flush, mount the saddle bracket in line with the Padbolt, ensuring that the bolt engages and disengages.
2. If the door is rebated, a hole may be drilled into the frame/post for the bolt to engage.
3. Hold Padbolt where you intend to install it. Mark hole position, drill pilot holes.

